

Covert Channels

- A covert channel is a path for an illegal flow of information within a system
- Any communication channel that can be exploited by a process to transfer information in a manner that violates the system's security policy
 - National Institute of Standards and Technology

16

STAM Center

ASU Engineering

Covert Channels

- A covert channel is a path for an illegal flow of information within a system
- Any communication channel that can be exploited by a process to transfer information in a manner that violates the system's security policy

 National Institute of Standards and Technology
- National Institute of Standards and Technology
 There are many types of covert channels within a computing system:
 Timing covert channels
 Methods to extract how much time a computation or a computational task takes?
 Termination covert channels
 Methods to detect if a computation terminates?

 - Probability covert channel

 - Methods to determine what the distribution of certain system events is? What control path does the program take?
 Resource utilization covert channels
 Approaches to establish some resource utilization level or if the resource is depleted?

 - Power covert channels

 Method to determine the amount energy consumed or required by a computational task?

17

STAM Center

ASU Engineering


Covert Channels

- There are many usage of covert channels to both improve and undermine the security of a computing system
 - Exfiltrate data from an otherwise secure system
 - Avoid detection of unauthorized access
 - Install, spread, or control malware on compromised systems
 - Circumvent content or resource filters
 - Bypass firewalls for unrestricted access
 - Malware authors use timing to detect analysis sandboxes


STAM Center SCUIL, HUNTED, AND ASSYMED INCHOLECTROMOS	Engineering Arizona State University
Covert Channels	
 Important characteristics of a covert channel Existence Is a channel present? Bandwidth 	
How much information can be transmitted? Neiscloss/paigy	

- Can the information be transmitted without loss or distortion? • Main example of covert channels

 - Covert storage channel
 - Covert timing channel




20




Covert Channels It is usually infeasible for realistic systems to eliminate every potential covert channel Mitigation techniques for covert channels Eliminate or minimize it by modifying or refining the system implementation Reduce potential covert channel bandwidth through noise injection into the channel Monitor it for patterns of usage that indicate potential exploitation

22

E.g., Intrusion detection



23



STAM Center

ASU Engineering

M. Backes, M. Dürmuth, S. Gerling, M. Pinkal, and C. Sporleder, "Acoustic side-channel attacks on printers." in USENIX Security sym- posium, 2010, pp. 307–322

M. Hutter and J.-M. Schmidt, "The temperature side channel and heating fault attacks," in International Conference on Smart Card Research and Advanced Applications. Springer, 2013, pp. 219–235

25

STAM Center

ASU Engineering

Side Channels

• Side-channel attacks are current and real threats

Security flaw lets attackers recover private keys from Qualcomm chips



[1] https://www.businesswire.com/news/home/20180808005464/en/Strategy-Analytics-Q1-2018-Smartphone-Apps-Processor

26

STAM Center

ASU Engineering


Side Channels

- Circumvent security measures
 - Qualcomm Secure Execution Environment (QSEE)
 - Hardware-isolated execution
 - Leaks private data, encryption keys, etc.
 - A cache side-channel is used to retrieve sensitive information


Intel CPUs impacted by new Zombieload side-channel attack


Researchers, academics detail new Microarchitectural Data Sampling (MDS) attack
















Physical access required	Physical access not required	
Power analysis	Timing side-channels	
Electromagnetic side-channels	Traffic analysis	
Optical side-channels		
Acoustic side-channels		
Thermal side-channels		
e-channel attacks require le-channels are based o	e physical access to the son timing	system




























Cache Side-Channel Attacks "Consider securing a smart card is harder than securing the hardware of an offsite server against side-channel attacks" Threat model Given: F: K X M -> D Where K is a finite set of key M is a finite set of messages D is an arbitrary set of ciphertext The attacker is assumed to have no access to the values of k and F (k,m) but he can measure/observe the characteristics of the physical implementation of F




Cache Side-Channel Attacks Caches used as the covert channel in many microarchitectural attacks (Spectre, Meltdown, Foreshadow, etc.) Cache side-channel attacks exploit intrinsic cache characteristics Caches are shared among processes Hit/miss latency Cache way and set organization Coherence invalidations


 Can circumvent security measures such as privilege checks, browser sandboxing, Address Space Layout Randomization, etc.


46




47











STAM Center SCUIL, TRUSTIO, AND A SOURCE MICROFILETRONICS	ASJ Inglineering Arizona State University
Cloud/FPGA Side-C	Channel Attacks
Ring Oscillator Temperature Sensor Ring Oscillator (RO) is a temperature-to-frequency transducer suitable for thermal monitoring on FPGAs	enable
Comparing RO counts (affected by temperature) to reference clock counts (not affected by temperature) allows one to measure relative RO frequency	Cloud +
Eduardo Boemo and Sergio López-Buedo. 1997. Thermal monitoring on FPGAs usin and Applications. Springer, 69–78.	ng ring-oscillators. In International Workshop on Field Programmable Logic


Side Channel Defenses Defense Leakage Reduction Noise Injection Key Update Side channel resistant PUFs Secure scan chains Metrics The amount of secret information that is vulnerable The number of samples from side channels needed to extract the secret information


53


Process Isolation Isolating a process is not trivial, and requires architectural, OS, compiler/runtime, and software support Isolating processes (e.g., using SGX) sacrifices hardware utilization Currently there is no simple way of using multi-core systems for secure computation Users have to choose between multiple powerful but unsecure cores, and slow, secure enclaves The tradeoff is coarse-grained and at design-time














STAM Center SICURE, TRUSTED, AND ASSURED MICROELECTRONICS		Arizona State University
	Upcoming Lectures	
 Hardware Root-o 	of-Trust Design	